

PowerMadd Sentinel Handguard mounting on Polaris ATV

34452 ATV/MX Mount

Note: May have clearance issues with Polaris OEM ATV windshield.

* Use these instructions along with the instructions provided with the mount kit.

Brake side:

Loosen brake assembly and move right to make room for the handguard mounting bracket. Mount bracket next to the brake assembly with the bracket going over the top of the brake lever as shown in photo. Mount bracket in handguard with one large space against right mounting tab. Adjust height of the handguard to personal preference and tighten all fasteners.



Throttle side:

Mount bracket just to the right of the throttle as you see in the photo. Mount bracket next to the left mounting tab on the handguard. Mounting bracket should be mounted in the handguard next to the left mounting tab as shown in the photo. Adjust handguard to your personal preference and tighten all fasteners.

